







Spare parts list of VEFBF2814RSL

No	PartNo	PartName	quantity	Sub-part No
2	K2010215	screw hole cover	1	
1	K4108950	screw hole cover	1	
3	K1887583	temperature sensor unit	1	
4	K2147628	right upper hinge cover	1	
102	K4188726	left upper hinge cover	1	
5	K1099091	screw	6	
6	K1416576	upper hinge part	1	
103	K1428326	left upper hinge part	1	
7	K1879352	LED light	1	
8	K2241138	display decorative board part	1	K2244871 K2141201 K2000841 K2000512 K2244844
9	K2000512	display board over	1	
10	K2244871	display decorative board-drawing	1	
11	K2244844	Display panel part	1	
13	K2000841	light cover	1	
14	K2141201	light cover	1	
15	K2226091	air duct part in refrigerator chamber	1	K1075936 K2191832 K1484305 K2191834 K2226664 K1485764 K1979452
16	K1979452	sponge block	1	
17	K1484305	sponge strip	2	
18	K2191834	wind gate foam	1	
19	K1075936	temperature sensor unit	1	
20	K1485764	Damper	1	
21	K2191832	air duct foam in refrigerator chamber	1	
22	K2226664	air duct cover-drawing in refrigerator chamber	1	
24	K2191838	air return cover in refrigerator chamber	1	
25	K1099068	self-tapping screw	5	
26	K1636839	installation button	6	
28	K1093509	self-tapping screw	15	
29	K1973614	drawer rail	1	

30	K1973739	wind channel part in freezer chamber	1	K1973734 K1620938 K1870599 K1973733 K1602291 K1973738 K1539491 K1909101 K1099082 K1620952 K1980462 K1989742 K1630438 K1115517
31	K1909101	temperature sensor unit	1	
32	K1973733	wind channel cover board in freezer chamber	1	
33	K1973738	Wind channel foam in freezer chamber	1	
34	K1099082	Cross recessed pan head tapping screw	5	
35	K1620938	back fan motor cover	1	
36	K1870599	refrigerator fan	1	
37	K1620952	back fan motor cover	1	
38	K1115517	Cross recessed pan head tapping screw	3	
39	K1602291	wind blade	1	
41	K1973734	wind channel cover board in freezer chamber	1	
42	K1980462	clapboard seat	1	
43	K1989742	insulation floss	1	
44	K1539491	sponge block	1	
45	K1630438	sponge strip	1	
46	K2001278	wing slice evaporator components	1	K1051790
104	K1051790	temperature sensor unit	1	
52	K1973694	right lower hinge part	1	
105	K1979797	left middle hinge part	1	
54	K1534952	screw	2	
55	K1096985	screw hole cover	2	
56	K2002446	screw hole cover	1	
57	K1129399	self-tapping screw	1	
58	K1980017	lower hinge parts	1	
59	K1428670	Adjustable foot	2	
60	K4198044	shelf part	3	
61	K4198054	crisper box cover part	1	
62	K4130592	crisper box part	1	
63	K1979990	freezer upper drawer-drawing	1	
64	K1973758	ice tray part	1	
65	K1973741	Ice box	1	
66	K4130594	middle drawer part	1	
67	K4130597	lower drawer part	1	
68	K2005148	lower cover part	1	
69	K2005146	small shelf	2	
70	K2005144	upper shelf	2	

73	K1973712	refrigerator door	1	K1467096 K1980778 K1099043 K1973701
72	K1980778	gasket part	1	
74	K1973701	door stopper	2	
75	K1467096	door stop	2	
76	K1099043	self-tapping screw	6	
77	K2005254	freezer door	1	K1980782 K1099040
78	K1980782	gasket part	1	
79	K1099040	self-tapping screw	7	
80	K1530937	power line	1	
82	K2106809	control board box cover part	1	
83	K2144344	Main board	1	
85	K1355795	dry filter	1	
86	K1639201	process tube	1	
87	K1980380	compressor parts	1	
111	K1512634	PTC	1	
112	K1563801	compressor overload protector	1	
113	K1563802	compressor running capacitor	1	
89	K1072839	Platen	1	
90	K1486161	bolt	2	
91	K1566176	steel sleeve	2	
92	K1111096	Right impact board	1	
96	K1522104	condenser fixed clip	1	
97	K1985969	evaporating dish	1	
98	K1091420	compressor grounding screw	2	
99	K1975840	compressor base part	1	K1103815
106	K1103815	roll wheel	2	
100	K1115414	special flange self-tapping screw	4	
101	K1110989	pipe plug	1	
107	K1092783	Door switch	1	
108	K4233145	logo scutcheon	1	K1980142 K1467020
109	K1980142	door stopper	2	
110	K1467020	door stop	2	